



## Diagnostic socket: List and location of components

B95 or D95 or K95




136703




136653

The diagnostic socket (1) is located under the centre front panel above the offset multimedia socket.



140465



140466

Note:

Use a small flat-blade screwdriver on the upper side sections (2) of the cover to remove the clips (3) and avoid damaging the brackets (4) .

Unclip the cover using a small flat-blade screwdriver at (2) .